

NightSearcher
Solaris Pro/ Pro-X User Manual

Thank you for purchasing the Solaris Pro/ Pro-X rechargeable fl odlight, our latest NightSearcher innovation offering an all in one solution.

Components List



Mode		Lumens	Solaris Pro Run times	Solaris Pro-X Run times
Boost	Full	16,000	2 hours 15 minutes	4 hour 30 minutes
	Half	8,000	4 hours 30 minutes	9 hours
	Low	4,000	9 hours	18 hours
Search	Full	5,000	6 hours	12 hours
	Half	2,500	12 hours	24 hours
	Low	1,250	24 hours	48 hours
Flood	Full	11,000	3 hours 45 minutes	7 hours 30 minutes
	Half	5,500	7 hours 30 minutes	15 hours
	Low	2,750	15 hours	30 hours
Weight			7kg	8.5kg
Battery			18Ah	36Ah
Product Code			NSSOLARISPRO	NSSOLARISPRO-X

Beam Distance	500 Max Metres		
IP Rating	IP65 Ingress Protection		
Charging Time	6 Hours Charging Time		
Supplied with	Floodlight, AC Charger, Shoulder Strap. Optional: Vehicle Charger and Stability pegs		
Dimensions	(L)517x(W)155x(D)220mm		

Quick Start Guide - Charging



①. Plug the charger into the socket on the Solaris Pro.



29. Plug the charger into a suitable socket outlet. Turn switch on.



3. The indicator on the charger will illuminate red when charging and green when fully charged.



②. The battery indicator on the charging panel will stay Green and flash to show the level of charge. When the battery is charged it will stop flashing

PLEASE NOTE:


The battery will reach optimum performance after 5 complete discharge/charge cycles.


Optional 12/24V Vehicle Charger is available. Part No: CHICSOLARISLITELION


Setting Up The Solaris Pro



Q. Pivot pole to required angle allowing pole to drop and lock into position. There are 4 angle positions, shown below.










Control Panel



Display colours while charging:

- Flashing Green Charging
- Green Fully charged

Display colours while in operation:

- Blue Normal operation
- Green Average battery
- Red Low battery
- Red Flashing Very low battery

Operating The Solaris Pro



Press the power button to turn the Solaris Pro on or off.

Push and hold power button while flood light on for flashing I ht mode, press once more to turn off flashing mode



THERE ARE TWO WAYS TO ADJUST THE BRIGHTNESS LEVELS:

1. With lamp on, push the settings button to change brightness level. Low/Half/Full. OR



2. With the lamp on, press the increase/decrease time buttons, this will automatically increase or decrease the brightest level.



CHANGING THE LIGHT OUTPUT:

With lamp on push and hold to change light output: Flood/Spot/Boost.





The Solaris Pro can be set to operate the number of hours you require - up to 24 hours.



To programme a runtime, press the up or down button to increase/decrease time. The egg timer symbol will appear on the display to indicate you have set a time.



Attaching The Shoulder Strap

Supplied with a high quality adjustable shoulder strap. Making it comfortable to carry the Solaris Pro, whilst keeping your hands free to perform other tasks. See **Fig 2**. showing where to attach the shoulder straps.

Fig 2.





Using The Solaris Pro While Its Charging

MAINS AND VEHICLE CHARGER

While connected to a charger, the lamp will function. To protect the battery and charger, the light will operate with reduced functions. Each light mode will only operate on the lowest light level.

Emergency Mode

The Solaris Pro can be used as an emergency light. If a charger is connected and the power fails, the light will illuminate.

TO ACTIVATE:

- Power unit on
- Connect charger
- Switch power on
- Lamp will now illuminate if power fails

IMPORTANT SAFETY INFORMATION:

- Never submerge in water.
- If you suspect the unit has water inside, do not use or attempt to recharge.
- Dropping the Solaris Pro may damage the battery or circuit components inside.
- IF THE SOLARIS PRO HAS BEEN SUBMERGED IN WATER OR SUSTAINED DAMAGE IT COULD BE A FIRE HAZARD. DO NOT USE THE PRODUCT. Place outdoors in a non-combustible container well away from flammable materials. DO NOT RECHARGE THE BATTERY AND CONTACT NIGHTSEARCHER.
- Never use the charger if the leads, contacts or casings are damaged. Do not use any chargers other than those provided.
- Avoid charging the battery in temperatures below 0°C or exposing the battery to temperatures below -5°C or above 40°C.
- Never expose the charger to rain, moisture or damp. If you suspect any of these have occurred then do not use the charger.
- Always check with your airline before attempting to transport by air.
- Do not cover/obstruct light head while in use
- Do not shine the light directly into people's eyes, as it may damage their eyesight.
- Keep out of reach of children.
- In case of any problems or questions please contact NightSearcher Limited or an authorised distributor.

Safe Disposal Of Waste Electrical Products





If at any time, you need to dispose of this product or parts of this product: please note that waste electrical products and batteries should not be disposed of with ordinary household waste. Recycle where facilities exist. Check with your local authority for recycling advice. Alternatively, NightSearcher is happy to take receipt of this product at end-of-life and will recycle it on your behalf.

Warranty Terms - Standard 3 years

All NightSearcher products have a 3-year standard warranty on all manufacturing defects and 1-year warranty on all rechargeable batteries from the date of purchase.



Extended Warranty:

You have the option to extend the warranty of the product to 5 years for manufacturing defects. Registration of the product must be made within one month of purchase by sending us an email sales@nightsearcher.co.uk. In the message please state in your own words that you would like to register your NightSearcher product for the extended warranty.

To view NightSearcher's warranty policy, please visit:

http://nightsearcher.com/en/warranty.html or scan the QR code.

UK:

NightSearcher Limited, Unit 4 Applied House, Fitzherbert Spur, Farlington, Portsmouth, Hampshire, PO6 1TT, UK T: +44 (0)23 9238 9774 • E: sales@nightsearcher.co.uk • W: www.nightsearcher.co.uk

EUROPE:

NightSearcher Limited, Garbary 53, Poznan Poland.

T: +44 239 216 1126 • E: exportsales@nightsearcher.com • W: www.nightsearcher.com

The contents of this manual are subject to change without prior notice. We take no responsibility for errors or admissions.